

JOHN DEERE XUV 825i GATOR™

UTILITY VEHICLE OPERATORS

MANUAL OMM173973

CONTENTS OF THE OPERATOR'S MANUAL

YOUR VEHICLE (MAIN CONTENTS)

DRIVER AND PASSENGER SAFETY (SEAT BELTS, SRS AND CHILD PROTECTION)

INSTRUMENTS AND CONTROLS (INDICATORS, GAUGES, INFORMATION DISPLAY, DASHBOARD, AND STEERING CONTROL)

FEATURES (CLIMATE CONTROL, AUDIO, STEERING WHEEL, SECURITY AND CRUISE CONTROL)

BEFORE DRIVING (FUEL, VEHICLE BREAK-IN AND CARGO LOADING)

DRIVING (ENGINE AND TRANSMISSION OPERATION)

MAINTENANCE (MINDER, FLUID CHECKING, MINOR SERVICES AND VEHICLE STORAGE)

TAKING CARE OF THE UNEXPECTED (FLAT TIRE, DEAD BATTERY, OVERHEATING FUSES)

TECHNICAL INFORMATION (VEHICLE SPECIFICATIONS, TIRES, AND EMISSIONS CONTROLS)

WARRANTY AND CUSTOMER RELATIONS

INSTANT DOWNLOAD